# 3 Port Solenoid Valve




Reduced power consumption:

Reduced power of the second control of the s

(Conventional: 2.0 W) \* With DC light

# Power consumption reduced by power saving circuit.

Power consumption is decreased by approx. 1/3 by reducing the wattage required to hold the valve in an energized state. (effective energizing time is over 40 ms at 24 VDC.) Refer to electrical power waveform as shown below.



Series VP300

# M Built-in full-wave rectifier (AC)

**Noise reduction** 

Noise is considerably reduced by changing it to DC mode via a full-wave rectifier.

- Reduced apparent power
  Conventional: 5.6 va Æ 1.55 va
- M Longer life expectancy: 50 million cycles or more

(Conventional: 20 million cycles) \* Based on SMC test conditions

M Built-in strainer in the pilot valve

Unexpected troubles due to foreign matter can be prevented. Note) Be sure to mount an air filter on the inlet side.

Rubber material: HNBR Ozone-resistant specification

\* The pilot valve poppet is made of FKM.








Series VP300/500/700



# **Model Selection by Operating Conditions** 1



### Solenoid Valve: Single Unit




Note) Only DIN and conduit terminal types can be set for AC mode.

# **Model Selection by Operating Conditions 2**



### Solenoid Valve: Manifold



Note) Supply pressure to 1(P) ports and exhaust air from 3(R) ports on both sides for 10 stations or more

# **Model Selection by Operating Conditions** ③


**Air Operated Valve: Single Unit** 

		Series	Sonic conductance C [dm³/(s·bar)]	Type of actuation	Port size	Voltage	Electrical entry	Light/surge voltage suppressor	Manual override	
		VPA300	4.2	N.C.  (A)  2  12  1 3  (P) (R)	1/8 1/4					
ed valve	Body ported	VPA500	8.9	N.O.  (A) 2 12 1 3 (P)(R)	1/4 3/8					P. 2
		VPA700	15.3	For vacuum N.C./N.O. (A) 2 12 1 3 (P)(R)	3/8 1/2					
Air operated valve		VPA300	3.8	N.C.  (A) 2 12 13 (P)(R)  N.O.  (A) 2	1/8 1/4				_	
	Base mounted	VPA500	8.8	12 1 3 (P)(R)  For vacuum N.C.  (A) 2 12 12 14 14	1/4 3/8					P. 30
		VPA700	15.0	N.O.  (A)  2  12  1 3 (P)(R)	3/8 1/2					

# **Model Selection by Operating Conditions 4**



### Air Operated Valve: Manifold



Note) Supply pressure to 1(P) ports and exhaust air from 3(R) ports on both sides for 10 stations or more

# Rubber Seal 3 Port/Pilot Poppet Type **Body Ported/Single Unit**


# VP300/500/700 Series



Refer to the electrical entry for details



Note) Pressure specifications: 0.7 MPa, DC or 24 VAC only Only applies to X500 and X505 for made-to-order specifications



<sup>\*</sup> LN and MN types are with 2 sockets.

\* Refer to page 4 when different length of lead wire for L/M-type plug connector is required.

\* Refer to page 5 for details on the DIN (EN175301-803) terminal

Note) With the same specifications as the DC type, all lead wire entries for the 24 VAC type are CE/UKCA marking compliant



When using the surge voltage suppressor type, residual voltage will remain. Refer to page 1300 for



CE/UKCA DC

# Pilot Poppet Type Body Ported/Single Unit Series VP300/500/700

Low power consumption 1.5 W (DC)
Possible to use as either a selector or divider valve
Possible to change from N.C. to N.O.



 Refer to back page 8 for changing the type of actuation.

# Possible to use in vacuum applications







### **External Pilot**

Use external pilot type in the following cases:

- For vacuum or for low pressure 0.2 MPa or less
- · When having P port downsized in diameter
- When using A port as the atmospheric releasing port, e.g. air blower



Made to Order (Refer to page 24 for details.)

X500

Pilot exhaust port with piping thread (M3) specification

### **Specifications**

Fluid		Air		
Type of actuation		N.C. or N.O. (Convertible)		
Internal pilot	Standard	0.2 to 0.7		
Operating pressure range (MPa)	High-pressure type	0.2 to 1.0		
External pilot	Standard	-100 kPa to 0.7		
External pilot Operating pressure range (MPa)	High-pressure type	-100 kPa to 1.0		
Operating pressure range (MFa)	Pilot pressure range	Same as operating pressure (Min. 0.2 MPa)		
Ambient and fluid temperat	ure (C)	-10 to 50 (No freezing)		
Max. operating frequency (I	·lz)	5		
Manual override		Non-locking push type Push-turn locking slotted type Push-turn locking lever type		
Pilot exhaust type		Individual exhaust		
Lubrication		Not required		
Mounting orientation		Unrestricted		
Impact/Vibration resistance	(m/s²) Note)	300/50		
Enclosure		Dust-tight (IP65 for D, Y, T)		

Note) Impact resistance: No malfunction occurred when it is tested in the axial direction and at the right

angles to the main valve and armature in both energized and de-energized states

every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was

performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

### **Solenoid Specifications**

Electrical entry			Grommet (G), (H) L-type plug connector (L) M-type plug connector (M)	DIN terminal (D) DIN (EN175301-803) terminal (Y) Conduit terminal (T)	
			G, H, L, M	D, Y, T	
Cail rated valtage (V)	DC		24,	12	
Coil rated voltage (V)	AC (50/60 Hz)		100, 110, 200, 220, 240		
Allowable voltage fluctuation			10% of rate	ed voltage*	
Dower concumption (W)	DC	Standard	1.5 (With light: 1.55)	1.5 (With light: 1.75)	
Power consumption (W)	ЪС	With power saving circuit	0.55 (With light only)	0.75 (With light only)	
		100 V			
		110 V			
		[115 V]			
Apparent power	AC	200 V	1.55 (With light: 1.65)	1.55 (With light: 1.7)	
(VA)Note 1)		220 V			
		[230 V]			
		240 V			
Surge voltage suppressor			Diode (Non-polar type: Varistor)		
Indicator light			LED (Neon bulb is used for AC mode of D, Y, T.)		

Note 1) It is in common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.

Note 2) Allowable voltage fluctuation is -15% to +5% of the rated voltage for 115 VAC or 230 VAC.

Note 3) Since voltage drops due to the internal circuit in S, Z, T types (with power saving circuit), the allowable voltage fluctuation should be within the following range.

24 VDC: -7% to +10% 12 VDC: -4% to +10%

### Response Time

		Response time ms (at 0.5 MPa)					
Model	Pressure specifications	Without light/surge	With light/surge ve	oltage suppressor	AC		
		voltage suppressor	S, Z type	R, U type	AC		
VP342	Standard (0.2 to 0.7)	13 or less	38 or less	16 or less	38 or less		
VF342	High-pressure type (0.2 to 1.0)	17 or less	42 or less	20 or less	42 or less		
VP542	Standard (0.2 to 0.7)	14 or less	39 or less	17 or less	39 or less		
VF342	High-pressure type (0.2 to 1.0)	18 or less	43 or less	21 or less	43 or less		
VP742	Standard (0.2 to 0.7)	19 or less	44 or less	22 or less	44 or less		
VF/42	High-pressure type (0.2 to 1.0)	22 or less	47 or less	25 or less	47 or less		

Note) Based on dynamic performance test, JIS B 8375-1981. (Coil temperature: 20C, at rated voltage)



### Flow Characteristics/Mass

Model	Port size	Port size $1 \leftrightarrow 2 (P \leftrightarrow A)$		$2 \leftrightarrow 3 \ (A \leftrightarrow R)$			→ R)	Mass (g) Note 1)			
Model		C [dm³/(s·bar)]	b	Cv	Q [l/min] (ANR)Note 2)	C [dm³/(s·bar)]	b	Cv	Q [d/min] (ANR)Note 2)	Grommet	DIN terminal
VP342	1/8	3.5	0.26	0.8	868	3.6	0.26	0.9	893	149	185
VP342	1/4	4.2	0.22	1.0	1018	4.2	0.23	1.0	1023	145	181
VP542	1/4	7.9	0.21	1.8	1903	7.2	0.27	1.8	1797	249	285
VP342	3/8	8.9	0.16	2.2	2085	8.9	0.20	2.1	2132	241	277
VP742	3/8	11.9	0.21	2.7	2867	11.8	0.20	2.7	2826	484	520
VP/42	1/2	15.1	0.21	3.6	3637	15.3	0.22	3.7	3707	467	503

Note 1) Values without bracket

Note 2) These valves have been calculated according to ISO6358 and indicate the flow rate under standard conditions with an inlet pressure of 0.6 MPa (relative pressure) and a pressure drop of 0.1 MPa.

### Application Example

### (1) Blow-off valve




**External pilot** 

### (2) Pressure release valve




**External pilot** 

(3) Selector valve




**External pilot** 

(4) Valve for vacuum




(5) Divider valve




(6) Single-acting cylinder drive



(7) Double-acting cylinder drive



(8) Double-acting cylinder drive (Exhaust centre)




### Construction

### **Body ported**

### JIS symbol

olo oyillooi					
Pilot type	N.C.	N.O.			
Internal pilot	(A) 2 1 3 (P)(R)	(A) 2 1 3 (P)(R)			
External pilot	(A) 2 1 3 (P)(R)				



### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-casted	White
2	Adapter plate	Resin	Grey
3	End plate	Resin	White
4	Piston	Resin	
5	Spool valve	Aluminum/HNBR	
6	Retainer	Resin	
7	Spring	Stainless steel	

**Bracket Assembly Part No.** 

Description	Model	Part no.
	VP342	VP300-227-1A
Bracket	VP542	VP500-227-1A
(With 2 screws)	VP742	VP700-227-1A

### **Replacement Parts**

No.	Description	Part no.	Note
8	Pilot valve assembly	Refer to "How to Order Pilot Valve Assembly" on page 4.	Built-in strainer




# Pilot Poppet Type Body Ported/Single Unit Series VP300/500/700

### **How to Order Pilot Valve Assembly**



When only the pilot valve assembly is replaced, it is not possible to change from V211 (Grommet or L/M-type) to V212 (DIN or Conduit type), or vice versa.



### **⚠** Caution

For V212 (DIN or Conduit type), the coil specification and voltage (including light/surge voltage suppressor) cannot be changed by changing the pilot valve assembly.




Tightening torque of the pilot valve assembly mounting screw M2.5: 0.32 N⋅m




### Series VP300/Body Ported/Dimensions


### Grommet (G)




# **Grommet (G)**DC without light/surge voltage suppressor




# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)



### Conduit terminal (T)




[ ] valves: without indicator light





# Pilot Poppet Type Body Ported/Single Unit Series VP300/500/700

### **Series VP500/Body Ported/Dimensions**


### Grommet (G)









# Grommet (G) DC without light/surge voltage suppressor




# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)



### Conduit terminal (T)




[ ] valves: Without indicator light




### Series VP700/Body Ported/Dimensions


### Grommet (G)



M-type


plug connector (M)







# blnd counector (P) (Lead wire length)

L-type







Unless otherwise indicated, dimensions are the same as Grommet (G).



中

paracasasas

# Rubber Seal 3 Port/Pilot Poppet Type Base Mounted/Single Unit

# VP300/500/700 Series

How to Order




Note) Only DIN and conduit terminal types are available for AC mode.

Refer to the electrical entry for details



Note) Pressure specifications: 0.7 MPa, DC or 24 VAC only Only applies to X500 and X505 for made-to-order specifications



	Grommet	L-type plug connector	M-type plug connector	DIN terminal	DIN (EN175301-803) terminal	Conduit terminal
	G: Lead wire length 300 mm H: Lead wire length 600 mm  G: Lead wire length 300 mm H: Lead wire length 300 mm C Without light/ surge voltage	L: With lead wire (length 300 mm)  LN: Without lead wire	M: With lead wire (length 300 mm)  MN: Without lead wire	[IP65 compatible]  D: With connector	Y: With connector	T: Conduit terminal
	suppressor	Without connector	Without connector	Without connector	Without connector	
CE/UKCA DC		•	•	•	•	•
compliant 40 Note						


\* LN and MN types are with 2 sockets.

compliant AC No

\* Refer to page 4 when different length of lead wire for L/M-type plug connector is required

\* Refer to page 5 for details on the DIN (EN175301-803) terminal.

Note) With the same specifications as the DC type, all lead wire entries for the 24 VAC type are CE/UKCA marking compliant.



● Light/surge voltage suppressor □C							
Nil	Without light/surge voltage suppressor	0	0				
S	With surge voltage suppressor	0	Note)				
Z	With light/surge voltage suppressor	0	0				
R	With surge voltage suppressor (Non-polar)	0	_				
U	With light/surge voltage suppressor (Non-polar)	0	_				

Note) There is no S option for AC mode, since a rectifier prevents surge voltage generation.

 In the DIN terminal type, since a light is installed in the connector, DOZ, DOU, YOZ, YOU are not available.

### **⚠** Caution

When using the surge voltage suppressor type, residual voltage will remain. Refer to page 1300 for details.



Low power consumption 1.5 W (DC) Possible to use as either a selector or divider valve Possible to change from N.C. to N.O.



· Refer to back page 8 for changing the type of actuation.

### Possible to use in vacuum applications

Up to -100 kPa



Series VP300



Series VP500



### **External Pilot**

Use external pilot type in the following cases:

- · For vacuum or for low pressure 0.2 MPa or less
- When having P port downsized in diameter
- · When using A port as the atmospheric releasing port, e.g. air blower
- · If manifold, external pilot piping can be centralized in manifold base.



Made to Order (Refer to page 24 for details.)

X500

Pilot exhaust port with piping thread (M3) specification

### **Specifications**

Fluid		Air	
Type of actuation		N.C. or N.O. (Convertible)	
Internal pilot	Standard	0.2 to 0.7	
Operating pressure range (MPa)	High-pressure type	0.2 to 1.0	
External nilet	Standard	-100 kPa to 0.7	
External pilot Operating pressure range (MPa)	High-pressure type	-100 kPa to 1.0	
Operating pressure range (MFa)	Pilot pressure range	Same as operating pressure (Min. 0.2 MPa)	
Ambient and fluid temperate	ure (C)	-10 to 50 (No freezing)	
Max. operating frequency (H	Hz)	5	
		Non-locking push type	
Manual override		Push-turn locking slotted type	
		Push-turn locking lever type	
Pilot exhaust type		Individual exhaust	
Lubrication		Not required	
Mounting orientation		Unrestricted	
Impact/Vibration resistance	(m/s²) Note)	300/50	
Enclosure		Dust-tight (IP65 for D, Y, T)	

Note) Impact resistance: No malfunction occurred when tested in both the axial and right angle directions of main valve and armature (tested in both energized and de-energized states).

(Values at the initial period).

Vibration resistance: No malfunction occurred when tested in a one-sweep test between 45 and 2000 Hz, in both the axial and right angle directions of main valve and armature (tested in both energized and de-energized states). (Values at the initial period).

### Solenoid Specifications

Electrical entry			Grommet (G), (H) L-type plug connector (L) M-type plug connector (M)	DIN terminal (D) DIN (EN175301-803) terminal (Y) Conduit terminal (T)			
			G, H, L, M	D, Y, T			
Cail rated valtage (\( \)	DC		24,	12			
Coil rated voltage (V)	AC	(50/60 Hz)	100, 110, 20	00, 220, 240			
Allowable voltage flu	uctua	ation	10% of rated	voltage Notes)			
Power consumption (W)	DC	Standard	1.5 (With light: 1.55)	1.5 (With light: 1.75)			
Power consumption (w)	DC	With power saving circuit	0.55 (With light only)	0.75 (With light only)			
		100 V					
		110 V					
		[115 V]					
Apparent power	AC	200 V	1.55 (With light: 1.65)	1.55 (With light: 1.7)			
(VA) Notes)		220 V					
		[230 V]					
		240 V					
Surge voltage suppr	esso	r	Diode (Non-pola	ar type: Varistor)			
Indicator light			LED (Neon bulb is used	for AC mode of D, Y, T.)			

Note 1) It is in common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.

Note 2) Allowable voltage fluctuation is -15% to +5% of the rated voltage for 115 VAC or 230 VAC.

Note 3) Since voltage drops due to the internal circuit in S, Z, T types (with power saving circuit), the allowable voltage fluctuation should be within the following range.

24 VDC: -7% to +10% 12 VDC: -4% to +10%

### **Response Time**

			Response time	ms (at 0.5 MPa)	
Model	Pressure specifications	Without light/surge	With light/surge vo	oltage suppressor	AC
		voltage suppressor	S, Z type	R, U type	AC
VP344	Standard (0.2 to 0.7)	13 or less	38 or less	16 or less	38 or less
VF 344	High-pressure type (0.2 to 1.0)	17 or less	42 or less	20 or less	42 or less
VP544	Standard (0.2 to 0.7)	14 or less	39 or less	17 or less	39 or less
VF 344	High-pressure type (0.2 to 1.0)	18 or less	43 or less	21 or less	43 or less
VP744	Standard (0.2 to 0.7)	19 or less	44 or less	22 or less	44 or less
VF/44	High-pressure type (0.2 to 1.0)	22 or less	47 or less	25 or less	47 or less

Note) Based on dynamic performance test, JIS B 8375-1981. (Coil temperature: 20C, at rated voltage)



# Pilot Poppet Type Base Mounted/Single Unit Series VP300/500/700


### Flow Characteristics/Mass

Model	Port size		$1 \leftrightarrow 2$	2 (P ←	→ A)		$2 \leftrightarrow 3$	3 (A ←	→ R)	Mass (g) Note 1)		
Wodei	FUIT SIZE	C [dm³/(s·bar)]	b	Cv	Q [l/min] (ANR)Note 2)	C [dm³/(s·bar)]	b	Cv	Q [d/min] (ANR)Note 2)	Grommet	DIN terminal	
VP344	1/8	3.6 0.22 0.8		8.0	872	3.5	0.24	8.0	858	216 (149)	252 (185)	
	1/4	3.9	0.22	0.9	945	3.8	0.14	0.9	881	211 (149)	247 (185)	
VP544	1/4	7.5	0.16	1.7	1757	7.3	0.20	1.7	1749	370 (245)	406 (281)	
VF344	3/8	8.8	0.07	2.0	1967	8.8	0.13	2.0	2029	362 (245)	398 (281)	
VP744	3/8	12.9	0.10	2.9	2929	13.3	0.24	3.1	3260	676 (459)	712 (495)	
VF/44	1/2	14.7	0.05	3.3	3256	15.0	0.17	3.4	3534	658 (459)	694 (495)	

Note 1) ( ) valves: Values without sub-plate

Note 2) These valves have been calculated according to ISO6358 and indicate the flow rate under standard conditions with an inlet pressure of 0.6 MPa (relative pressure) and a pressure drop of 0.1 MPa.

### Application Example





**External pilot** 

X port

**External pilot** 

(5) Divider valve

(2) Pressure release valve




**External pilot** 

(3) Selector valve



(4) Valve for vacuum




**External pilot** 


(6) Single-acting cylinder drive



(7) Double-acting cylinder drive



(8) Double-acting cylinder drive (Exhaust centre)



### Construction

### **Base mounted**

JIS symbol


<del>0.0 0 y0 0</del>		
Pilot type	N.C.	N.O.
Internal pilot	(A) 2	(A) 2
•	1 3 (P)(R)	1 3 (P)(R)
External pilot	(A) 2 1 3 (P)(R)	(A) 2 1 3 (P)(R)

**Component Parts** 


No.	Description	Material	Note
1	Body	Aluminum die-casted	White
2	Adapter plate	Resin	Grey
3	End plate	Resin	White
4	Piston	Resin	
5	Spool valve	Aluminum/HNBR	
6	Retainer	Resin	
7	Spring	Stainless steel	

**Replacement Parts** 

No.	Description		Part no.	Part no.									
NO.	Description	VP344	VP344 VP544 VP744										
8	Pilot valve assembly	Refer to "How to O	Built-in strainer										
9	Gasket	VP300-217-1	VP500-217-1	VP700-217-1	HNBR								
10	Sub-plate	VP300-202-□	VP500-202-□	VP700-202-□	Aluminum die-casted								
_	Hexagon socket head bolt (1 pc.)	VP300-224-1 (M3 x 36)	VP500-224-1 (M4 x 46)	VP700-224-1 (M5 x 66)	For valve mounting								



### **How to Order Sub-plate**



Symbol VP344

2

1/8

1/4

VP544

1/4

3/8

## **Tightening Torque**

of Mounting Screw

M3:	0.8	N⋅m
M4:	1.4	$N \cdot m$
M5:	2.9	N⋅m




VP744

3/8

1/2

### **How to Order Pilot Valve Assembly**



### <u>∕!\</u> Caution

For V212 (DIN or Conduit type), the coil specification and voltage (including light/surge voltage suppressor) cannot be changed by changing the pilot valve assembly.

1 100 VAC

7 240 VAC

200 VAC

110 VAC [115 VAC] 4 220 VAC [230 VAC]

2

3

With power saving circuit (DC only)

Note) T type is only available for DC mode.



Tightening torque of the pilot valve assembly mounting screw M2.5: 0.32 N·m

V212


Pilot valve assembly





# Pilot Poppet Type Base Mounted/Single Unit Series VP300/500/700

### Series VP300/Base Mounted/Dimensions


### Grommet (G)









# Grommet (G) DC without light/surge voltage suppressor






Note) Refer to page 24 when piping to PE port is required.


# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)



### **Conduit terminal (T)**





[ ] valves: Without indicator light





### Series VP500/Base Mounted/Dimensions

### Grommet (G)











1/4, 3/8 13.5 2(A) port

Note) Refer to page 24 when piping to PE port is required.


### **Grommet (G)** DC without light/surge voltage suppressor




### L-type plug connector (L)




### M-type plug connector (M)



### DIN terminal (D, Y)



### Conduit terminal (T)




[ ] valves: Without indicator light





# Pilot Poppet Type Base Mounted/Single Unit Series VP300/500/700

### Series VP700/Base Mounted/Dimensions

### Grommet (G)









# DC without light/surge voltage suppressor (this property of the property of t

**Grommet (G)** 




Note) Refer to page 24 when piping to PE port is required.


# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)



### Conduit terminal (T)





[ ] valves: Without indicator light



# Rubber Seal/3 Port/Pilot Poppet Type Manifold Common Exhaust Type 41 / Individual Exhaust Type 42 Series VP300/500/700

### **How to Order Manifold**





# Pilot Poppet Type Common Exhaust Type 41 /Individual Exhaust Type 42 VP300/500/700 Series

**How to Order Valve** (With a gasket and two mounting bolts)

3 110 VAC [115 VAC] 4 220 VAC [230 VAC] 240 VAC B 24 VAC

Note) For triac output, refer to the


made-to-order specifications (X600).

Note) Only DIN and conduit terminal types are available for AC mode Refer to the electrical entry for details.



MPa, DC or 24 VAC only Only applies to X500 and X505 for made-to-order specifications





### Electrical entry

		•····· y				
	Grommet	L-type plug connector	M-type plug connector	DIN terminal	DIN (EN175301-803) terminal	Conduit terminal
	G: Lead wire length 300 mm H: Lead wire length 600 mm  G: Lead wire length 600 mm  H: Lead wire length 300 mm H: Lead wire length 600 mm DC Without light/surge voltage suppressor	L: With lead wire (length 300 mm)  LN: Without lead wire  LO: Without connector	M: With lead wire (length 300 mm)  MN: Without lead wire  MO: Without connector	D: With connector  D: With connector	Y: With connector  Yo: Without connector	T: Conduit terminal
OC	•	•	•	-	•	•
C Note)	_				•	•

\* LN and MN types are with 2 sockets.

CE/UKCA D compliant AC

- \* Refer to page 4 when different length of lead wire for L/M-type plug connector is required.
- \* Refer to page 5 for details on the DIN (EN175301-803) terminal.

Note) With the same specifications as the DC type, all lead wire entries for the 24 VAC type are CE/UKCA marking compliant.



# Piping is concentrated on the base side.

# All external pilots are gathered in the base.

Common external pilot port allows one piping.

### 2 types of exhaust ports

Common or individual exhaust type are available. For individual exhaust type, exhaust can be restricted.

# Easy to change between N.C. and N.O.

Type of actuation can be easily changed from normally closed to normally open by only changing the direction of a valve and end-plate 180°.



 Refer to back page 8 for changing the type of actuation.





### **Manifold Specifications**


		Pipir	ng specificat	tions			Manifold base
VP300 VV3 VP500 VV3 VP700 VV3	Base model	1P (SUP) port type	3R (EXH) port type	Port size	Applicable valve	Applicable stations Note)	Mose: W/ [a]
VP300	VV3P3-41		Common	1/4	\/D044	2 to 20 stations	W = 110n + 90
	VV3P3-42		Individual	1/4	VP344	2 to 20 stations	W = 110n + 90
	VV3P5-41	Common	Common	3/8	VP544	2 to 20 stations	W = 190n + 150
VF300	VV3P5-42	Common	Individual	3/0	VP544	2 to 20 stations	W = 190H + 150
	VV3P7-41		Common	1/2	VP744	2 to 20 stations	W = 410n + 380
VF700	VV3P7-42		Individual	1/2	VF/44	Z 10 ZU SIAIIONS	vv = 410N + 380

Note) Supply pressure to 1(P) ports and exhaust pressure from 3(R) ports on both sides for 10 stations or more.

### **Manifold Option**

Description	Part no.	Applicable manifold base model
Blanking plate assembly	VP300-25-1A	VV3P3
(With a gasket and two	VP500-25-1A	VV3P5
mounting bolts)	VP700-25-1A	VV3P7


### **How to Order Manifold Assembly (Example)**







### Series VP300/Dimensions

# Type 41/Common exhaust: VV3P3-41□-Stations 1-02 Grommet (G)





Note) Refer to page 24 when piping to PE port is required.



(Station n) ----- (Station 1)


# Suppressor 8.78 Approx. 300 8.78 80.5

**Grommet (G)** 


DC without light/surge voltage

Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	83.5	111	138.5	166	193.5	221	248.5	276	303.5	331	358.5	386	413.5	441	468.5	496	523.5	551	578.5
L2	68.5	96	123.5	151	178.5	206	233.5	261	288.5	316	343.5	371	398.5	426	453.5	481	508.5	536	563.5


# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)




### **Conduit terminal (T)**




[ ] valves: Without indicator light

### **Series VP300/Dimensions**


Type 42/Individual exhaust: VV3P3-42□-Stations 3-02



Note) Refer to page 24 when piping to PE port is required.




(Station n) ----- (Station 1)




Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	83.5	111	138.5	166	193.5	221	248.5	276	303.5	331	358.5	386	413.5	441	468.5	496	523.5	551	578.5
L2	68.5	96	123.5	151	178.5	206	233.5	261	288.5	316	343.5	371	398.5	426	453.5	481	508.5	536	563.5

### Grommet (G)


DC without light/surge voltage suppressor




# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)



### **Conduit terminal (T)**




[ ] valves: Without indicator light







### **Series VP500/Dimensions**

# Type 41/Common exhaust: VV3P5-41□-Stations 1-03 Grommet (G)





Note) Refer to page 24 when piping to PE port is required.



(Station n)	 	(	Station	1)	)

123.5	
Approx. 300 (Lead wire length)	63.8


DC without light/surge voltage

**Grommet (G)** 


suppressor

Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	95	128	161	194	227	260	293	326	359	392	425	458	491	524	557	590	623	656	689
L2	80	113	146	179	212	245	278	311	344	377	410	443	476	509	542	575	608	641	674


# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)




### Conduit terminal (T)




[ ] valves: Without indicator light




### **Series VP500/Dimensions**




# Grommet (G) DC without light/surge voltage suppressor




# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)




### **Conduit terminal (T)**




[ ] valves: Without indicator light


### **Series VP700/Dimensions**

# Type 41/Common exhaust: VV3P7-41□-Stations 1-04 Grommet (G)






Note) Refer to page 24 when piping to PE port is required.




(Station n) ----- (Station 1)

# Grommet (G) DC without light/surge voltage suppressor




Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	115	156	197	238	279	320	361	402	443	484	525	566	607	648	689	730	771	812	853
L <sub>2</sub>	99	140	181	222	263	304	345	386	427	468	509	550	591	632	673	714	755	796	837


# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)




### **Conduit terminal (T)**




[ ] valves: Without indicator light




### **Series VP700/Dimensions**




# Grommet (G) DC without light/surge voltage suppressor




# L-type plug connector (L)




# M-type plug connector (M)



### DIN terminal (D, Y)



### **Conduit terminal (T)**



[ ] valves: Without indicator light

### VP300/500/700 Series

# **Made to Order**






### 1 Pilot Exhaust Port with Piping Thread (M3) Specification

In this specification, piping to the pilot exhaust port (PE port) is available when the valve is used in an environment where the exhaust from the pilot valve is not allowable, or intrusion of ambient dust should be prevented.


### **How to Order Valve**



### 2 Body Ported Interchangeable Specification with the Previous Valve Mounting Hole Pitch Type


The mounting hole has been changed to the long type in order to provide interchangeability with the previous VP300/500 series.

### **How to Order Valve**




Note) VP742 is not available because the mounting hole pitch is the same as the previous type.






### **VP542**



### 3 TRIAC Output Specification

For AC type valve, use this specification when the pilot valve is not recovered even though valve power supply is turned OFF at the equipment using output unit with large leakage voltage over 8% of the rated voltage (TRIAC output such as PLC or SSR, etc.). Combination with low wattage specification is not possible.

### **How to Order Valve**






# 3 Port/Air Operated Valve Body Ported/Single Unit

# Series VPA300/500/700







**How to Order** 

### **Specifications**

Fluid		Air			
Type of actuation		N.C. or N.O. (Convertible)			
Operating pressure range (MPa)	Standard	0.2 to 1.0			
Operating pressure range (MFa)	For vacuum	-100 kPa to 0.2			
Pilot pressure (MPa)		0.2 to 1.0 (Equivalent to the operating pressure or more)			
Ambient and fluid temperature (°C)		-10 to 50 (No freezing)			
Lubrication		Not required			
Mounting orientation		Unrestricted			
Impact/Vibration resistance (m/	(s²) Note)	300/50			

Note) Impact resistance: No malfunction occurred when tested in both the axial and right angle directions

of main valve and armature (tested in both energized and de-energized states).

(Values at the initial period).

 $\label{thm:linear_variation} \mbox{Vibration resistance: No malfunction occurred when tested in a one-sweep test between 45 and 2000}$ 

Hz, in both the axial and right angle directions of main valve and armature (tested in both energized and de-energized states). (Values at the initial period).

### Flow Characteristics/Mass

Model	Port size		$1 \leftrightarrow 2 \ (P \leftrightarrow A)$				2 ↔ 3	$(A \leftrightarrow R)$		Maga (a) Note 1)
Model	Wodel Port size		b	Cv	Q [d/min] (ANR)Note 2)	C [dm³/(s·bar)]	b	Cv	Q [d/min] (ANR)Note 2)	Mass (g) Note 1)
VPA342	1/8	3.5	0.26	0.8	868	3.6	0.26	0.9	893	118
VFA342	1/4	4.2	0.22	1.0	1018	4.2	0.23	1.0	1023	114
VPA542	1/4	7.9	0.21	1.8	1903	7.2	0.27	1.8	1797	237
VFAJ42	3/8	8.9	0.16	2.2	2085	8.9	0.20	2.1	2132	229
VPA742	3/8	11.9	0.21	2.7	2867	11.8	0.20	2.7	2826	501
VFA/42	1/2	15.1	0.21	3.6	3637	15.3	0.22	3.7	3707	484

Note 1) Values without brackets

Note 2) These valves have been calculated according to ISO6358 and indicate the flow rate under standard conditions with an inlet pressure of 0.6 MPa (relative pressure) and a pressure drop of 0.1 MPa.



Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions I for SMC Products" (M-E03-3) for Common Precautions.



 Refer to back page 8 for changing the type of actuation.




### Construction


### **Standard**

JIS symbol

	N.C.	N.O.
Standard	12	12 1 3 (P)(R)
For vacuum	12	(A) 2 1 3 (P)(R)



### For vacuum



### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-casted	White
2	Adapter plate	Aluminum die-casted	Grey
3	End plate	Resin	White
4	Piston	Resin	
5	Spool valve	Aluminum/HNBR	
6	Retainer	Resin	
7	Spring	Stainless steel	


### **Bracket Assembly Part No.**

Description	Model	Part no.			
	VPA342	VP300-227-1A			
Bracket (With 2 screws)	VPA542	VP500-227-1A			
(VVIII1 2 3016W3)	VPA742	VP700-227-1A			




### Series VPA300/Body Ported/Dimensions

### Standard/VPA342-1- $^{01}_{02}\Box^{A}_{B}$ (-F)




### For vacuum/VPA342V-1-01 ☐ A (-F)




### Series VPA500/Body Ported/Dimensions

### Standard/VPA542-1-<sup>02</sup><sub>03</sub>□<sup>A</sup><sub>B</sub>(-F)




### For vacuum/VPA542V-1- ${}_{03}^{02}\square_{B}^{A}$ (-F)




### Series VPA700/Body Ported/Dimensions

### Standard/VPA742-1-03/□ A/(-F)





### For vacuum/VPA742V-1-03□A (-F)



# 3 Port/Air Operated Valve **Base Mounted/Single Unit**

# Series VPA300/500/700





### **Specifications**

Fluid		Air			
Type of actuation		N.C. or N.O. (Convertible)			
Operating pressure range (MPa)	Standard	0.2 to 1.0			
Operating pressure range (wra)	For vacuum	-100 kPa to 0.2			
Pilot pressure (MPa)		0.2 to 1.0 (Equivalent to the operating pressure or more)			
Ambient and fluid temperature (°C)		-10 to 50 (No freezing)			
Lubrication		Not required			
Mounting orientation		Unrestricted			
Impact/Vibration resistance (m/s	s²) Note)	300/50			

Note) Impact resistance:

No malfunction occurred when tested in both the axial and right angle directions of main valve and armature (tested in both energized and de-energized states).

(Values at the initial period).

Vibration resistance: No malfunction occurred when tested in a one-sweep test between 45 and 2000 Hz. in both the axial and right angle directions of main valve and armature (tested

### Flow Characteristics/Mass

Model	Model Port size $1 \leftrightarrow 2 (P \leftrightarrow A)$						2 ↔ 3 (	$A \leftrightarrow R$ )		Mana (a) Note 1)
iviodei	Model Port size		b	Cv	Q [l/min] (ANR)Note 2)	C [dm³/(s·bar)]	b	Cv	Q [d/min] (ANR)Note 2)	Mass (g) Note 1)
VPA344	1/8	3.6	0.22	0.8	872	3.5	0.24	0.8	858	185 (118)
VPA344	1/4	3.9	0.22	0.9	945	3.8	0.14	0.9	881	180 (118)
VPA544	1/4	7.5	0.16	1.7	1757	7.3	0.20	1.7	1749	358 (233)
VFA544	3/8	8.8	0.07	2.0	1968	8.8	0.13	2.0	2029	350 (233)
VPA744	3/8	12.9	0.10	2.9	2929	13.3	0.24	3.1	3260	693 (476)
VFA/44	1/2	14.7	0.05	3.3	3256	15.0	0.17	3.4	3534	675 (476)

Note 1) ( ) valves: Values without sub-plate

Note 2) These valves have been calculated according to ISO6358 and indicate the flow rate under standard conditions with an inlet pressure of 0.6 MPa (relative pressure) and a pressure drop of 0.1 MPa.



Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions I for SMC Products" (M-E03-3) for Common Precautions.



Refer to back page 8 for changing the type of




### Construction


JIS symbol

JIS SYI	IIDOI	
	N.C.	N.O.
Standard	12 (A) 2 (A) 1 (B) (A) 1 (B) (A) (B) (B) (B) (B) (B) (B) (B) (B) (B) (B	12
For vacuum	12 13 (P) (R)	12 (A) 2 (A) 1 (B) (A) 1 (B) (A) (A) (A) (A) (A) (A) (A) (A) (A) (A

### **Standard**



### For vacuum



### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-casted	White
2	Adapter plate	Aluminum die-casted	Grey
3	End plate	Resin	White
4	Piston	Resin	
5	Spool valve	Aluminum/HNBR	
6	Retainer	Resin	
7	Spring	Stainless steel	

### **Replacement Parts**


No.	Description	Part no.			Note
		VP344	VP544	VP744	Note
8	Gasket	VP300-217-1	VP500-217-1	VP700-217-1	HNBR
9	Sub-plate	VP300-202-□	VP500-202-□	VP700-202-□	Aluminum die-casted
_	Hexagon socket head bolt (1 pc.)	VP300-224-1 (M3 x 36)	VP500-224-1 (M4 x 46)	VP700-224-1 (M5 x 66)	For valve mounting

### 

Tightening Torque of Mounting Screw

M3: 0.8 N·m M4: 1.4 N·m M5: 2.9 N·m

### **How to Order Sub-plate**







# Air Operated Valve Base Mounted/Single Unit Series VPA300/500/700

### **Series VPA300/Base Mounted/Dimensions**

# Standard/VPA344-1- $^{01}_{02}\Box^{A}_{B}$




# For vacuum/VPA344V-1- $^{01}_{02}\Box^{A}_{B}$





# Series VPA300/500/700

# **Series VPA500/Base Mounted/Dimensions**

# Standard/VPA544-1-02 B M5 x 0.8 (Breathing hole) 1/4, 3/8 (For mounting) 47, 17.6








52


### For vacuum/VPA544V-1-02 B 74.5 73.5 28.5 M5 x 0.8 28.5 (Breathing hole) 57 1/4, 3/8 1(P) port 2 x ø5.2 1/4, 3/8 (For mounting) 3(R) port 42 52 13.5 12.6 91 23 . 1/4, 3/8 13.5 2(A) port





# Air Operated Valve Base Mounted/Single Unit Series VPA300/500/700


### **Series VPA700/Base Mounted/Dimensions**




**SMC** 

# 3 Port/Air Operated Valve Manifold Common Exhaust Type 41 / Individual Exhaust Type 42 Series VPA300/500/700

### **How to Order Manifold**






### **Manifold Option**

Description	Part no.	Applicable manifold base model
Blanking plate assembly	VP300-25-1A	VV3PA3
(With a gasket and two mounting bolts)	VP500-25-1A	VV3PA5
(With a gasket and two mounting boile)	VP700-25-1A	VV3PA7



### How to Order Valve (With a gasket and two mounting bolts)



### **Manifold Specifications**

		Pipir	ng specificat	ions			Manifold base	
Series	Base model	1P (SUP) port type	3R (EXH) port type	Port size	Applicable valve	Applicable stations Note	Mass: W [g] Stations: n	
VPA300	VV3PA3-41		Common	1/4	VPA344	2 to 20 stations	W = 110n + 90	
VPASOU	VV3PA3-42		Individual	1/4	VPA344	2 to 20 Stations	vv = 110H + 90	
VPA500	VV3PA5-41	Common	Common	3/8	VPA544	2 to 20 stations	W = 190n + 150	
VPASOU	VV3PA5-42	Common	Individual	3/6	VPA544	2 to 20 Stations	W = 190H + 150	
VPA700 ─	VV3PA7-41	1 -	Common	1/0	VD 4 7 4 4	O to OO stations	W 410m . 200	
	VV3PA7-42		Individual	1/2	VPA744	2 to 20 stations	W = 410n + 380	




Note) Supply pressure to 1(P) ports and exhaust air from 3(R) ports on both sides for 10 stations or more.



 Refer to back page 8 for changing the type of actuation.

### **How to Order Manifold Assembly (Example)**






# Series VPA300/500/700


### **Series VPA300/Dimensions**

### Type 41/Common exhaust: VV3PA3-41-Stations 1-02



Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	83.5	111	138.5	166	193.5	221	248.5	276	303.5	331	358.5	386	413.5	441	468.5	496	523.5	551	578.5
L2	68.5	96	123.5	151	178.5	206	233.5	261	288.5	316	343.5	371	398.5	426	453.5	481	508.5	536	563.5

Type 42/Individual exhaust: VV3PA3-42-Stations 3-02




Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	83.5	111	138.5	166	193.5	221	248.5	276	303.5	331	358.5	386	413.5	441	468.5	496	523.5	551	578.5
L2	68.5	96	123.5	151	178.5	206	233.5	261	288.5	316	343.5	371	398.5	426	453.5	481	508.5	536	563.5

# Air Operated Valve Common Exhaust Type 41 /Individual Exhaust Type 42 Series VPA300/500/700


### **Series VPA500/Dimensions**

### Type 41/Common exhaust: VV3PA5-41-Stations 1-03



Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	95	128	161	194	227	260	293	326	359	392	425	458	491	524	557	590	623	656	689
L2	80	113	146	179	212	245	278	311	344	377	410	443	476	509	542	575	608	641	674

Type 42/Individual exhaust: VV3PA5-42-Stations 3-03




Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	95	128	161	194	227	260	293	326	359	392	425	458	491	524	557	590	623	656	689
L2	80	113	146	179	212	245	278	311	344	377	410	443	476	509	542	575	608	641	674

# Series VPA300/500/700


### **Series VPA700/Dimensions**

### Type 41/Common exhaust: VV3PA7-41-Stations 1-04



Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	115	156	197	238	279	320	361	402	443	484	525	566	607	648	689	730	771	812	853
L <sub>2</sub>	99	140	181	222	263	304	345	386	427	468	509	550	591	632	673	714	755	796	837

Type 42/Individual exhaust: VV3PA7-42-Stations 3-04



Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L <sub>1</sub>	115	156	197	238	279	320	361	402	443	484	525	566	607	648	689	730	771	812	853
L2	99	140	181	222	263	304	345	386	427	468	509	550	591	632	673	714	755	796	837





These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC) Note 1) and other safety regulations.

Note 1) ISO 4414: Pneumatic fluid power – General rules relating to systems.

ISO 4413: Hydraulic fluid power – General rules relating to systems.

IEC 60204-1: Safety of machinery - Electrical equipment of machines. (Part 1: General requirements)

ISO 10218: Manipulating industrial robots -Safety.

etc.

Caution: Operator error could result in injury or equipment damage.

**Warning:** Operator error could result in serious injury or loss of life.

⚠ Danger: In extreme conditions, there is a possibility of serious injury or loss of life.

# Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
  - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
  - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
  - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.





# **A**Caution

### The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

# Limited Warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited Warranty and Disclaimer" and "Compliance Requirements". Read and accept them before using the product.

### **Limited Warranty and Disclaimer**

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delive-red. Note 2)
  - Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.
  - This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
  - Note 2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

# **Compliance Requirements**

When the product is exported, strictly follow the laws required by the Ministry of Economy, Trade and Industry (Foreign Exchange and Foreign Trade Control Law).



Be sure to read before handling.


Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

#### **Manual Override**

# **Marning**


When no electric signal is applied to the solenoid valve. The manual override is used for switching the main valve. Connected actuator is started by manual operation. Use the manual override after confirming that there is no danger.


### ■ Non-locking push type



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.


### ■ Push-turn locking slotted type






Push the manual override button with a small flat head screwdriver until it stops. Turn it in the clockwise direction 90° to lock the manual. Turn it counterclockwise to release it.

### ■ Push-turn locking lever type





After pushing down, turn in the direction of the arrow. If it is not turned, it can be operated the same way as the non-locking type.

# **⚠** Caution

When locking the manual override with the push-turn locking type (D or E type), be sure to push it down before turning.

Turning without first pushing it down can cause damage to the manual override and other troubles such as air leakage, etc.


Do not apply excessive torque when turning the locking type manual override. (0.1 N·m)

### **How to Use L/M-Type Plug Connector**

# **A** Caution


### 1. Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



### 2. Crimping lead wires and sockets

Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area. (Please contact SMC for details on the crimping tool.)



Note) It is not necessary to crimp lead wires and socket if ordering the lead wire pre-connected model.


### 3. Attaching and detaching sockets with lead wire

#### Attachine

Insert the sockets into the square holes of the connector  $(\bigoplus, \bigcirc)$  indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

### Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.





Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

### **Plug Connector Lead Wire Length**

### **∧** Caution

Plug connector lead wires have a standard length of 300 mm, however, the following lengths are also available.

How	to Order Connector Assembly
DC	: V200-30-4A-
100 VAC	: V200-30-1A-
200 VAC	: V200-30-2A-
AC other volta	ges: V200-30-3A-
Without lead w (With connector and	rire: V200-30-A 2 pcs. of socket)
	<b>Lead wire length</b>
	Nil 300 mm

300 mm
600 mm
1000 mm
1500 mm
2000 mm
2500 mm
3000 mm
5000 mm

### **How to Order**

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

(Example) 2000 mm lead wire length:

DC	AC
VP342-5LO1-01A	VP342-1LO1-01A
V200-30-4A-20	V200-30-1A-20

### **How to Use DIN Terminal**

The DIN terminal type with an IP65 enclosure is protected against dust and water, however, it must not be used in water.

# **↑** Caution

#### Connection

- 1) Loosen the set screw and pull the connector out of the solenoid valve terminal block.
- After removing the set screw, insert a flat head screwdriver into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- Loosen the terminal screws on the terminal block, insert the core of the lead wire into the terminal, and attach securely with the terminal screws.
  - In addition, when using the DC mode type with a surge voltage suppressor (polar: S and Z types), connect wires corresponding to the polarity (+ or -) that is printed on the terminal block.
- 4) Tighten the ground nut to secure the wire. In the case of connecting wires, select cabtire cords carefully because if those out of the specified range (ø4.5 to ø7) are used, it will not be able to satisfy IP65 (enclosure). Tighten the ground nut and set screw within the specified range of torque.

### Changing the entry direction

After separating terminal block and housing, the cord entry direction can be changed by attaching the housing in the opposite direction.

Note) Make sure not to damage elements, etc., with the lead wires of the cord.

#### **Precautions**

Plug in and pull out the connector vertically without tilting to one side.


### Applicable cable

Cable O.D.: ø4.5 to ø7.

(Reference) 0.5 mm² to 1.5 mm², 2-core or 3-core, equivalent to JIS C 3306.

### Applicable crimped terminal

O terminal: R1.25-4M that is specified in JIS C 2805. Y terminal: 1.25-3L, which is released by JST Mfg. Co., Ltd. Stick terminal: size 1.5 or shorter.







Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

### **DIN (EN175301-803) Terminal**


Y type DIN terminal corresponds to the DIN connector with terminal pitch 10 mm, which complies with EN175301-803B. Since the terminal pitch is different from the D type DIN connector, these two types are not interchangeable.






### **How to Order DIN Connector**

# **<b> ⚠** Caution



With indicator light:
DC




Connector specification 61 D type 63 Y type


# • Rated voltage

06 12 VDC

01 100/110 VAC [115 VAC]02 200/220 VAC [230 VAC]07 240 VAC

### Circuit with indicator light (Built-in connector)





LED: Light emitting diode, R: Resistor NL: Neon bulb, R: Resistor

### DC (□Z) circuit



LED: Light emitting diode D: Protective diode

R: Resistor


### Back page 5


### **How to Use Conduit Terminal**

### **⚠** Caution

#### Connection


- Loosen the set screw and remove the terminal block cover from the terminal block.
- 2) Loosen the terminal screws on the terminal block, insert the core of the lead wire or crimped terminal into the terminal, and attach securely with the terminal screws.





In case of connecting wires, select cabtire cords carefully because if those out of the specified range ( $\emptyset4.5$  to  $\emptyset7$ ) are used, it will not be able to satisfy IP65 (enclosure).

Tighten the ground nut and set screw within the specified range of torque.



### Applicable cable

Cable O.D.: ø4.5 to ø7.

(Reference) 0.5 mm² to 1.5 mm², 2-core or 3-core, equivalent to JIS C 3306.

### Applicable crimped terminal

O terminal: Equivalent to R1.25-3 that is specified in JIS C 2805. Y terminal: Equivalent to 1.25-3, which is released by JST Mfg. Co., Ltd.

Note) Use O terminal when a ground terminal is used.






Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.

### Leakage Voltage

### **⚠** Caution

Especially when a resistor and a switching element are used in parallel or C-R device (surge voltage suppressor) is used for the protection of the switching device, note that leakage voltage will be increased by passing leakage voltage through the resistor and C-R device. Therefore, suppressor residual leakage voltage should be as follows.



DC coil

3% or less of the rated voltage

AC coil

8% or less of the rated voltage

### **Continuous Duty**

### **⚠** Caution


- If a valve is continuously energized for long periods of time, the rise in temperature due to heat-up of the coil assembly may cause a decline in solenoid valve performance, reduce service life, or have adverse effects on peripheral equipment. If the valve is continuously energized for a long time, or the total energizing time per day becomes longer than the non-energizing time, use a valve with power saving circuit.
  Also it is possible to reduce the energizing time by using a
  - Also, it is possible to reduce the energizing time by using a N.O. (normally open) valve.
- When the valve is mounted onto a control panel, take measures against radiation in order to keep the valve temperature within the specified range.

### **Light/Surge Voltage Suppressor**


### **∧** Caution

<DC>

■ Polar type



● Grommet or L/M-type plug connector
 With light/surge voltage suppressor (□Z)



DIN or Conduit terminal

With light/surge voltage suppressor (□Z)<sub>Polarity protection diode</sub>

(+) ○

LED


Diode

(-) ○


For DIN type, installed

■ Non-polar type

With surge voltage suppressor (□R)



Grommet or L/M-type plug connector
 With light/surge voltage suppressor (□U)



DIN or Conduit terminal

- Please connect correctly the lead wires to + (positive) and (negative) indications on the connector. (For non-polar type, the lead wires can be connected to either one.)
- When the valve with mis-wiring protection diode is used, the voltage will drop by approx. 1 V. Therefore, pay attention to the allowable voltage fluctuation (For details, refer to the solenoid specification of each type of valve).
- Solenoids, whose lead wires have been pre-wired: + (positive) side red and – (negative) side black.



in the connector



Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.


### **Light/Surge Voltage Suppressor**

### ■ With power saving circuit


Power consumption is decreased by approx. 1/3 by reducing the wattage required to hold the valve in an energized state. (Effective energizing time is over 40 ms at 24 VDC.)

Refer to the electrical power waveform as shown below.

### <Electrical power waveform of energy saving type>




• Since the voltage will drop by approx. 0.5 V due to the transistor, pay attention to the allowable voltage fluctuation. (For details, refer to the solenoid specifications of each type of valve.)




### <AC>

There is no S option, since a rectifier prevents surge voltage generation.

● Grommet or L/M-type plug connector
 With light/surge voltage suppressor (□Z)



◆ DIN or Conduit terminal
 With light/surge voltage suppressor (□Z)



### **∧** Caution

### Residual voltage of the surge voltage suppressor

Note) if a varistor or diode surge voltage suppressor is used, there is some residual voltage to the protection element and rated voltage. Therefore, refer to the table below and pay attention to the surge voltage protection on the controller side. Also, since the response time does change, refer to the specifications on page 2 and 9.

### **Residual Voltage**

Course coalte are accommonded	D	С	4.0
Surge voltage suppressor	24	12	AC
S, Z	Appro	x. 1 V	Approx. 1 V
R, U	Approx. 47 V	Approx. 32 V	_

### **Countermeasure for Surge Voltage Intrusion**

# **⚠** Caution

With non-polar type solenoid valves, at times of sudden interruption of the loading power supply, such as emergency shutdown, surge voltage intrusion may be generated from loading equipment with a large capacity (power consumption), and the solenoid valve in a deenergized state may switch over (see Figure 1).

When installing a breaker circuit for the loading power supply, consider using a solenoid valve with polarity (with polarity protection diode), or install a surge absorption diode between the loading equipment COM line and the output equipment COM line (see Figure 2).




Figure 1. Surge intrusion circuit example (NPN outlet example) (24 VDC)




Figure 2. Surge intrusion circuit example (NPN outlet example) (24 VDC)





Be sure to read before handling.

Refer to back pages 1 and 2 for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) for 3/4/5 Port Solenoid Valves Precautions.


### Type of Actuation Changing

# **△** Warning

When changing the actuation or restarting the valve after the change, make sure that safety is fully assured.

Example: Changing from N.C. to N.O.


### 1) Base mounted



- Remove the body from the sub-plate and reset the "▼" mark on the body corresponding to the "N.O." mark on the sub-plate as shown in the figure above.
- Remove the end plate from the body and rotate the end plate by 180° so that the "N.O." mark on the end plate is at the top of the valve.

Note) It is not necessary to change the piping when this is done.

### 2) Body ported



 Remove the end plate from the body and rotate the end plate by 180° to correspond the "N.O." mark on the end plate to the top of the valve.

Note) Piping should be arranged as follows.

Type Port of actuation	1P	2A	3R	
N.C.	Inlet side	Outlet side	Exhaust side	
N.O.	Exhaust side	Outlet side	Inlet side	

### **One-touch Fittings**

# **⚠** Caution

When fittings are used, they may interfere with others depending on their types and sizes. Therefore, the dimensions of the fittings to be used should first be confirmed in their respective catalogues.

Fittings compliant with the VP series are stated below. If the fitting within the applicable range is selected, there will not be any interference.

### Applicable Fittings: Series KQ2H, KQ2S

Applicable Fittings. Series KQZH, KQZS											
Series	Piping	Port	Applicable tubing O.D.								
	port	size	ø3.2	ø4	ø6	ø8	ø10	ø12	ø16		
VP(A)300	1P, 2A, 3R	1/8, 1/4									
	Х	M5									
VP(A)500	1P, 2A, 3R	1/4, 3/8									
	Х	1/8									
VP(A)700	1P, 2A, 3R	3/8, 1/2									
	Х	1/8									
VV3P(A)3 Manifold base	1P, 2A, 3R	1/4									
	Х	M5									
VV3P(A)5 Manifold base	1P, 2A, 3R	3/8									
	Х	M5									
VV3P(A)7 Manifold base	1P, 2A, 3R	1/2									
	Х	1/8									

### 

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC) 1), and other safety regulations.

Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate

injury.

Warning indicates a hazard with a medium level of risk
 Warning: which, if not avoided, could result in death or serious

njury.

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious

njury.

ISO 4414: Pneumatic fluid power – General rules relating to systems.
 ISO 4413: Hydraulic fluid power – General rules relating to systems.
 IEC 60204-1: Safety of machinery – Electrical equipment of machines.
 (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

### Marning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
  - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
  - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
  - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

### **↑** Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary. If anything is unclear, contact your nearest sales branch.

# Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".Read and accept them before using the product.

### **Limited warranty and Disclaimer**

- The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first. <sup>2</sup>)
   Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
- 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### Compliance Requirements


- The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

### **↑** Caution

# SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country.

Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.



### **SMC Corporation (Europe)**

Austria +43 (0)2262622800 www.smc.at Belgium +32 (0)33551464 www.smc.be Bulgaria +359 (0)2807670 www.smc.bg Croatia +385 (0)13707288 www.smc.hr Czech Republic +420 541424611 www.smc.cz +45 70252900 www.smcdk.com Denmark Estonia +372 651 0370 www.smcee.ee Finland +358 207513513 www.smc.fi France +33 (0)164761000 www.smc-france.fr Germany +49 (0)61034020 www.smc.de www.smchellas.gr +30 210 2717265 Greece Hungary +36 23513000 www.smc.hu Ireland +353 (0)14039000 www.smcautomation.ie +39 03990691 Italy www.smcitalia.it Latvia +371 67817700 www.smc.lv

office@smc.at
info@smc.be
office@smc.bg
office@smc.hr
office@smc.cz
smc@smcdk.com
info@smcee.ee
smcfi@smc.fi
supportclient@smc-france.fr
info@smc.de
sales@smchellas.gr
office@smc.hu
sales@smcautomation.ie
mailbox@smcitalia.it
info@smc.ly

Lithuania +370 5 2308118 www.smclt.lt Netherlands +31 (0)205318888 www.smc.nl Norway +47 67129020 www.smc-norge.no Poland +48 222119600 www.smc.pl Portugal +351 214724500 www.smc.eu Romania +40 213205111 www.smcromania.ro Russia +7 (812)3036600 www.smc.eu Slovakia +421 (0)413213212 www.smc.sk Slovenia +386 (0)73885412 www.smc.si Spain +34 945184100 www.smc.eu +46 (0)86031240 Sweden www.smc.nu **Switzerland** +41 (0)523963131 www.smc.ch Turkey +90 212 489 0 440 www.smcturkey.com.tr UK +44 (0)845 121 5122 www.smc.uk

info@smclt.lt
info@smc.nl
post@smc-norge.no
office@smc.pl
apoioclientept@smc.smces.es
smcromania@smcromania.ro
sales@smcru.com
office@smc.sk
office@smc.sk
office@smc.si
post@smc.smces.es
smc@smc.nu
info@smc.ch
info@smc.ch
info@smc.turkey.com.tr
sales@smc.uk

South Africa +27 10 900 1233 www.smcza.co.za zasales@smcza.co.za